



How to upgrade firmware of Cudy Router?

1. Unzip the firmware.
2. Power ON Cudy device, wait for LED become solid.
3. Connect to Cudy's network via Wi-Fi or Ethernet.
4. Open a web browser and go to **http://cudy.net** or **http://192.168.10.1**



6. Use ***admin*** as password to login.
7. Go to ***Advanced Settings -> Firmware***, Choose the firmware you unzipped to upload.



8. Waiting 5 minutes for the router restart.